



1. Double-click to open the upgrade tool




2. Select HP 500 USB Driver




3. Click "Recover" button



4. Click "Yes" to continue



5. Click "OK", Recover success.



6. Note:

Only versions of FW with O1127v1 can be upgraded, while upgrades with other versions and upgrade OK, it will prompt that this operation is not supported.

